




### LCD Drawing:



### 5 Keys for operation:



### Select MODE key:

Mode Key	Mode switch
C_MODE	Time mode → Alarm mode → Timer mode
A_MODE	Time mode → Alarm mode
T_MODE	Time mode → Timer mode

### Function:

- 1、 Normal Timekeeping Mode  
Display: time, date (2000-2099), weekday, temperature, and with 12/24 hour format.
- 2、 Daily Music Alarm with Snooze Mode  
In this mode, you can set alarm time, snooze interval time and select music.
- 3、 Count-down Timer Mode  
The countdown timer can be set from 23h 59m 59s to 0h 00m 00s.
- 4、 Thermometer Mode  
You can select Celsius and Fahrenheit by press DOWN key.  
Temperature range: -10°C -50°C (16°F -122°F), and resolution: ±0.5°C.
- 5、 Backlight  
In any mode, press DK key to turn on 7 colors backlight for 5 second.